

6-3. Initialization Items to initialize

The following items must be initialized for normal system operation in cases such as after the battery is reconnected, or maintenance is performed on the vehicle.

Item	When to initialize	Reference
Intuitive parking assist	<ul style="list-style-type: none">• After reconnecting or changing the battery• After changing a fuse	P. 526
Engine oil maintenance data	<ul style="list-style-type: none">• After changing engine oil	P. 429
Tire pressure warning system	<ul style="list-style-type: none">• When changing the tire inflation pressure by changing traveling speed or load weight, etc.• When changing the tire size.	P. 440

6-3. Initialization